

Varenr. 51216

Udskiftning af pakningssæt ved låge:

Pakken indeholder:

2 stk. pakning



Vejledning:

Er pakningerne blevet hårde og utætte, kan de skiftes på følgende måde:

- Pakningen er limet fast, så den "rykkes" ud.
- Rengør falsen/rillen for limrester.
- Ny pakning trykkes ind i falsen/rillen – dette gøres lettest med en spartel.
- Den nye pakning kan evt. limes fast med varmebestandigt lim.

Herefter er brændeovnen igen klar til brug.

Modellnr. 51216

Austausch des Dichtungssets bei der Tür:

Paketinhalt: 2 Stck. Dichtungen



Anleitung

Sind die Dichtungen verhärtet und undicht, können diese wie folgt ausgetauscht werden:

- Die Dichtung ist festgeklebt, deswegen diese „herausziehen“.
- Die Rille saubermachen.
- Neue Dichtung in die Rille hereindrücken – ist einfach mit einem Spachtel.

Benutzen Sie eventuell einen wärmebeständigen Kleber, wenn es nicht ausreichend ist, die Dichtung einfach hereinzudrücken

Sie können jetzt den Kaminofen wieder benutzen.

Item No. 51216

Exchange of the door sealing:

The package contains:



Directions:

If the sealing has become worn out or hard, it should be replaced like this:

- The sealing has been mounted with glue, so it needs to be tugged out
- Clean the fold/groove for soot and remains from the glue
- Press the new sealing into the fold/groove - this is easily done by the use of a palette knife
- You may also use heat-resistant glue for the mounting

Hereafter you can use the stove again.